

Basket Strainer Parts



Basket



SS-308 Basket



Grid



Brass Tail nut



Zinc Lock Nut

Basket Parts

Part No.	Model	Piece
301-001	SS 304	Basket
301-021	SS 305	Basket
301-002	SS 306	Basket
301-003	SS 410	Basket
301-004	SS 420	Basket
301-005	SS 430	Basket
301-006	SS 440	Basket
301-010	SS 308	Basket
301-011	SS 310	Grid
302-101	-	Rubber Gasket
302-102	-	Paper Follower

Brushed Stainless Basket Strainer/Disposer Parts

Part No.	Model	Piece
301-017	BS 313B	Basket
301-018	BS 314-DFC	Cover (with rubber seal)
301-019	BS 315	Basket
301-020	BS 315 & BS 316	Grid

Locknuts and Tail nuts for Models SS-304, SS-410, SS-430

Part No.	Piece
302-103	Zinc Lock Nut
302-104	Brass Lock Nut
302-105	Zinc Tail Nut
302-106	Brass Tail Nut

Cut Type Locknut for Models SS-306, SS-420, SS-440, SN-307B

Part No.	Piece
302-105	Zinc Tail Nut
302-106	Brass Tail Nut
302-107	Zinc Lock Nut for Cup Type
302-108	Brass Lock Nut for Cup Type
302-109	Plastic Tail nut Washer
302-199	1-1/2" x 4" Chrome Tailpiece



WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer, and lead, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.