





Illustrated Parts

Order by Part Number


Stopper - Plastic
186589



Removable Splash Guard
1016




Sink Flange - Polished Stainless
1017




Mounting Assembly Kit - 1824

Fiber Gasket
Backup Flange
Screws (x3)
Mounting Ring
Snap Ring
Cushion Mount
Lower Mounting Ring




Drain Elbow Kit - 1026

Rubber Gasket
Screws
Drain Elbow



Replacement Power Cord Kit
1024




Garbage Disposals

MODEL GXP33c

Other Available Accessories



Air Switch Remote Controller

- Installs into existing sink hole to operate disposer with plunger air switch.
- Perfect application for island countertops or where electrical switch is unavailable.
- No wiring connections or code restrictions.

Air Switch Base Unit

| Air Switch Remote Controller | ARC-4200 |
|--|-------------|
| Additional Air Switch Button Finish Options: | |
| Chrome | AS-4201-CH |
| Satin Nickel | AS-4201-SN |
| Polished Brass | AS-4201-BR |
| White | AS-4201-WH |
| Almond | AS-4201-AL |
| Biscuit | AS-4201-BIS |

Optional:

Dishwasher Connector Kit
1023



Unjamming Wrench
1037

